

Water Sample Collection Instructions

For dental unit water line analysis:

The sample collection tube will be transparent (clear) and have a numbered green cap

- Ensure hands are covered by clean gloves
- Place a clean napkin down on work space
- Remove collection tubes from Dentisafe kit
- Remove green cap and place face down on the napkin
- Flush DUWL for approximately 10 seconds before filling tube
- Fill collection tube and place green cap back onto the tube
- Fill out order form on the back side with the corresponding cap number and test that will be performed

After collecting all of the samples, ensure that the caps are tightly closed onto the collection tubes. Place sample tubes into the silver mailing envelope with provided ice pack and order form. Remove the protected adhesive and ensure that the envelope is securely closed. Place prepaid shipping label onto the front of the envelope and place in your mailbox for pickup on the same day on which you collected your water sample.

If you have any questions before or during sample collection, please contact your Dentisafe representative, or at support@dentisafe.com